



SIZE:148x210mm



## Collapsible Garden Wagon



### ! WARNING

**EN**

- This is a utility rather than a toy, suitable for camping, shopping, garden, traveling to the beach and other places.
- Store in a cool dry place.
- Please do not drag the product with a car, bicycle, or a motorcycle.
- For use by adults only!
- The color of the bag cloth might become faded, please wash it alone to help prevent from the bag's colors bleeding out into your other laundry.
- We will not be liable for any direct or indirect personal injury and property damage resulting from the incorrect use of this product the installation process.
- Sekey wagons come with a 1-year warranty. How to use the warranty service? Login your account > choose "My orders"> find the order ID> click "Contact seller".

**DE**

- Dies ist ein Gebrauchsgegenstand und kein Spielzeug. Sie können es für Camping, Einkaufen, Gartenarbeit, Reisen, am Strand und anderen Orten nutzen.
- Lagern Sie den Wagen kühl und trocken.
- Bitte ziehen Sie das Produkt nicht mit einem Auto, Fahrrad und oder einem Motorrad.
- Nur von Erwachsenen zu benutzen!
- Wir haften nicht für direkte oder indirekte Personen-oder Sachschäden, die durch unsachgemäße Verwendung dieses Produkts entstehen.
- Die Farbe des Stoffes kann verblassen. Bitte waschen Sie den Stoff separat oder mit ähnlichen Farben, um Verfärbungen zu vermeiden.
- Sekey-Wagen haben eine 1-Jahres-Garantie. Wie nehme ich die Garantie in Anspruch? Melden Sie sich bei Ihrem Konto an > wählen Sie "Meine Bestellungen" > finden Sie die Bestellnummer > klicken Sie auf "Verkäufer kontaktieren".

**FR**

- Cet un outil pratique n'est pas un jouet, il peut être utilisé en accessoire de camping, en sac de courses, pour le jardinage et comme chariot de transport pour aller à la plage etc.
- Conserver ce produit dans un endroit sec et à l'abri de l'humidité.
- Ne pas trainer ce produit derrière un vélo ou une moto.
- Ce produit doit être manipulé par un adulte.
- Il peut apparaître une légère décoloration lors du premier lavage de la poche, donc lavez séparément, lavez avec une brosse et du savon, évitez le lavage machine ou à sec.

**IT**

- Questa è un'utilità piuttosto che un giocattolo, adatto per il campeggio, lo shopping, il giardino, la spiaggia ecc.
- Si prega di collocarlo in un luogo fresco e asciutto.
- Si prega di non trascinarlo il prodotto con una bicicletta o una moto.
- Il prodotto è solo per gli adulti.
- Il colore del sacchetto potrebbe diventare sbiadito, si prega di lavarla separatamente.
- Non saremo responsabili delle lesioni personali e dei danni all'approprietà diretti o indiretti causati dall'uso sbagliato di questo prodotto.
- I vagoni Sekey sono coperti da una garanzia di 1 anno. Come utilizzare il servizio di garanzia? Accedi al tuo account > scegli "I miei ordini" > trova l'ID dell'ordine > fai clic su "Contatta il venditore".

**ES**


- Esta es una herramienta de utilidad en lugar de un juguete, adecuado para acampar, ir de compras, jardín, playa y otros lugares.
- Póngalo en un lugar fresco y seco.
- No arrastre el producto con una bicicleta o una motocicleta.
- Este producto es para el uso de personas adultas solamente.
- La bolsa de tela a la hora de limpiarla podría perderse, por favor lavar por separado.
- Si se causan daños y pérdidas de bienes debido al uso incorrecto, nuestra compañía no asumirá ninguna responsabilidad.
- Los vagones Sekey vienen con una garantía de 1 año. ¿Cómo utilizar el servicio de garantía? Inicie sesión en su cuenta > elija "Mis pedidos" > busque el ID del pedido > haga clic en "Contactar con el vendedor".

**HONGKONG UKING TRADING LIMITED**  
 Address: Room 63, 7/F, Woon Lee Commercial Building, 7-9 Austin Ave, Tsim Sha Tsui, Kowloon, Hong Kong  
 E-Mail: customercare@ukingglobal.com

**SEKEY LTD**  
 Address: 41 Cambert Lane, Manchester, England, M18 8HA  
 E-Mail: customercare@ukingglobal.com

**Salcar GmbH**  
 Address: An der Hebemärchte 6, 04316 Leipzig, Germany  
 E-Mail: info@sekeymail.com  
 Tel: 0341 25257850





**Sekey Group**  
 Address: 2 E VALLEY BLVD STE 280, ALHAMBRA, CA 91801, USA  
 E-Mail: info@sekeygroup.com







sekeymail.com





MADE IN CHINA




### OPEN

### CLOSE

 <b>#4014</b> <table border="0"> <tr><td>Unfold Size(Inch)</td><td>35.43"Lx18.89"Wx40.15"H</td></tr> <tr><td>Caster Type</td><td>1.5"x6"</td></tr> <tr><td>Unfold Size(cm)</td><td>90x48x102cm</td></tr> <tr><td>Caster Type</td><td>4x15cm</td></tr> </table>	Unfold Size(Inch)	35.43"Lx18.89"Wx40.15"H	Caster Type	1.5"x6"	Unfold Size(cm)	90x48x102cm	Caster Type	4x15cm	 <b>#4015</b> <table border="0"> <tr><td>Unfold Size(Inch)</td><td>35.43"Lx20.07"Wx40.15"H</td></tr> <tr><td>Caster Type</td><td>4"x7", Brake</td></tr> <tr><td>Unfold Size(cm)</td><td>90x51x102cm</td></tr> <tr><td>Caster Type</td><td>9x18cm, Brake</td></tr> </table>	Unfold Size(Inch)	35.43"Lx20.07"Wx40.15"H	Caster Type	4"x7", Brake	Unfold Size(cm)	90x51x102cm	Caster Type	9x18cm, Brake
Unfold Size(Inch)	35.43"Lx18.89"Wx40.15"H																
Caster Type	1.5"x6"																
Unfold Size(cm)	90x48x102cm																
Caster Type	4x15cm																
Unfold Size(Inch)	35.43"Lx20.07"Wx40.15"H																
Caster Type	4"x7", Brake																
Unfold Size(cm)	90x51x102cm																
Caster Type	9x18cm, Brake																
 <b>#4010</b> <table border="0"> <tr><td>Unfold Size(Inch)</td><td>36.22"Lx22.83"Wx39.37"H</td></tr> <tr><td>Caster Type</td><td>1.5"x7", Brake</td></tr> <tr><td>Unfold Size(cm)</td><td>92x57x101cm</td></tr> <tr><td>Caster Type</td><td>4x18cm, Brake</td></tr> </table>	Unfold Size(Inch)	36.22"Lx22.83"Wx39.37"H	Caster Type	1.5"x7", Brake	Unfold Size(cm)	92x57x101cm	Caster Type	4x18cm, Brake	 <b>#4011</b> <table border="0"> <tr><td>Unfold Size(Inch)</td><td>36.22"Lx22.44"Wx38.19"H</td></tr> <tr><td>Caster Type</td><td>4"x7", Brake</td></tr> <tr><td>Unfold Size(cm)</td><td>92x57x101cm</td></tr> <tr><td>Caster Type</td><td>9x18cm, Brake</td></tr> </table>	Unfold Size(Inch)	36.22"Lx22.44"Wx38.19"H	Caster Type	4"x7", Brake	Unfold Size(cm)	92x57x101cm	Caster Type	9x18cm, Brake
Unfold Size(Inch)	36.22"Lx22.83"Wx39.37"H																
Caster Type	1.5"x7", Brake																
Unfold Size(cm)	92x57x101cm																
Caster Type	4x18cm, Brake																
Unfold Size(Inch)	36.22"Lx22.44"Wx38.19"H																
Caster Type	4"x7", Brake																
Unfold Size(cm)	92x57x101cm																
Caster Type	9x18cm, Brake																

 <b>#4013</b> <table border="0"> <tr><td>Unfold Size(Inch)</td><td>48.4"Lx22.44"Wx</td></tr> <tr><td>Caster Type</td><td>4"x7", Brake</td></tr> <tr><td>Unfold Size(cm)</td><td>123x57x58cm</td></tr> <tr><td>Caster Type</td><td>9x17cm, Brake</td></tr> </table>	Unfold Size(Inch)	48.4"Lx22.44"Wx	Caster Type	4"x7", Brake	Unfold Size(cm)	123x57x58cm	Caster Type	9x17cm, Brake	 <b>#3011</b> <table border="0"> <tr><td>Unfold Size(Inch)</td><td>35.43"Lx20.07"Wx40.15"H</td></tr> <tr><td>Caster Type</td><td>1"x7"</td></tr> <tr><td>Unfold Size(cm)</td><td>90x51x102cm</td></tr> <tr><td>Caster Type</td><td>2x17cm</td></tr> </table>	Unfold Size(Inch)	35.43"Lx20.07"Wx40.15"H	Caster Type	1"x7"	Unfold Size(cm)	90x51x102cm	Caster Type	2x17cm
Unfold Size(Inch)	48.4"Lx22.44"Wx																
Caster Type	4"x7", Brake																
Unfold Size(cm)	123x57x58cm																
Caster Type	9x17cm, Brake																
Unfold Size(Inch)	35.43"Lx20.07"Wx40.15"H																
Caster Type	1"x7"																
Unfold Size(cm)	90x51x102cm																
Caster Type	2x17cm																
 <b>#3017</b> <table border="0"> <tr><td>Unfold Size(Inch)</td><td>38.58"Lx23.23"Wx42.13"H</td></tr> <tr><td>Caster Type</td><td>4"x7", Brake</td></tr> <tr><td>Unfold Size(cm)</td><td>98x59x107cm</td></tr> <tr><td>Caster Type</td><td>9x17cm, Brake</td></tr> </table>	Unfold Size(Inch)	38.58"Lx23.23"Wx42.13"H	Caster Type	4"x7", Brake	Unfold Size(cm)	98x59x107cm	Caster Type	9x17cm, Brake									
Unfold Size(Inch)	38.58"Lx23.23"Wx42.13"H																
Caster Type	4"x7", Brake																
Unfold Size(cm)	98x59x107cm																
Caster Type	9x17cm, Brake																