


SEKEY FOLDING BEACH WAGON

USER MANUAL



EN

Operation Instructions

Step 1

Take the cart frame, fabric basket and storage bag out the box. Spread out the cart frame on a flat place in order to prevent damage.

Step 2

Put the fabric basket into the cart, Put the fabric basket into the cart, open the Velcro on the fabric basket and wrap it around the cart frame, then attach it to the bag as seen in the diagram.

. Open the Velcro and wrap it around the cart frame, then attach it to the bag as seen in the diagram.

Step 3

The bottom Velcro under the fabric basket should be fastened to the center bar of frame. And attach the basket's backside to the back of the cart frame in the same way that it was attached to the front of the frame.

Step 4

When the installation is finished, your cart is ready to use.

Step 5

In order to store away the cart, you only need to lift the loop located in the middle of the fabric basket and squeeze the cart to the smallest size. When folded, be sure to stick the Velcro tight and put the storage bag onto the folded cart.

Step 6

Your cart is ready to store away for saving space.

Warning

- 1.This is a utility wagon rather than a toy, suitable for traveling to beach,camping, fishing, gardening and other outdoor activities.
- 2.Store in a cool dry place. Be sure to wipe dry the frame or let it cool place.
- 3.Please do not drag the product with a car, bicycle, and or a motorcycle
- 4.For use by adults only!
- 5.The maximum drag weight is of 175 pounds (80 kg).
- 6.The color of the cloth might become faded, please wash it alone to help prevent the cloth colors from bleeding out into your other laundry.
- 7.We will not be liable for any direct or indirect personal injury and property damage resulting from the incorrect use of this product.

Technical parameters

Folding dimensions: approx 82 x 68 x 23cm (32 x 26.8 x 9inches)
Open dimensions: 108 x 68 x 63cm (42.5 x 26.8 x 25inches)
Loading basket size: 86 x 45 x 36cm (34 x 17.7 x 14inches)
Weight: 11.2KG (24.7 pounds)
Loading capacity: 80KG (175 pounds)

Packing list

Beach cart x1
User manual x1
Storage bag x 1

Warranty period

For any possible questions, please kindly contact us via info@salcar.de. We will response within 24 hours on weekdays or 48 hours on weekends :)

All parts of this product except those that are consumable parts, come with a one year warranty. Damage by the following conditions is not covered in the warranty.

1. Loading more than the limited weight.
2. Man-made intentional damage.
- 3.Going beyond the warranty period.

DE

Bedienungsanleitungen

Schritt 1

Nehmen Sie den Wagenrahmen, den Stoffkorb und Aufbewahrungstasche aus der Box. Stellen Sie den Wagenrahmen auf eine flache Oberfläche, um zu verhindern, dass er während des Aufbaus wegrollt oder sich bewegt. Öffnen Sie die seitlichen Schnallen, damit der Trolley auseinandergefaltet werden kann.

Schritt 2

Legen Sie den Wagen mit dem Stoffkorb aus. Öffnen Sie den Klettverschluss und wickeln Sie ihn um den Rahmen. Befestigen Sie diesen dann an der Tasche.

Schritt 3

Der untere Klettverschluss des Stoffkorbs sollte an der Mittelstange des Wagenrahmens befestigt werden. Die Korbrückseite wird an der Rückseite des Wagengestells auf die gleiche Weise befestigt wie auf der Vorderseite.

Schritt 4

Wenn die Installation abgeschlossen ist, ist Ihr Warenkorb einsatzbereit.

Schritt 5

Zum Verstauen des Wagens, heben die Schlaufe in der Mitte des Stoffkorbs an und schieben den Wagen in Richtung Mitte zusammen (der Wagen kann so mit geschlossenem Verschluss hochgeklappt werden).

Schritt 6

Ihr Warenkorb ist bereit zum Platzsparen.

Warnung

- 1.Der Trolley ist kein Spielzeug. Er eignet sich für Camping, Einkaufen, Gartenarbeit, Reisen, Strand und anderen Outdoor-Aktivitäten.
- 2.An einem kühlen, trockenen Ort aufbewahren.
- 3.Bitte ziehen Sie das Produkt nicht mit einem Auto, Fahrrad oder Motorrad.Nur für Erwachsene geeignet!
- 4.Die maximale Tragfähigkeit beträgt 80 kg.
- 5.Die Farbe des Stoffkorbs kann im Laufe der Zeit verblassen. Bitte waschen Sie diesen allein, um zu verhindern, dass die Farbe eventuell auf andere Wäscheteile abfärbt
- 6.Wir sind nicht haftbar für direkte oder indirekte Sach- oder Personenschäden, resultierend aus zweckentfremdeter Nutzung und/oder unsachgemäßer Anwendung des Produktes.

Technische Daten

Faltmaße: ca. 82 x 68 x 23cm
Entfaltet maße: ca. 108 x 68 x 63cm
Taschengröße: ca. 86 x 45 x 36cm
Gewicht: ca. 11,2kg
Ladegewicht Max: 80kg

Packliste

Bollerwagen x1
Tragetasche x1
Bedienungsanleitung x1

Garantiegewährleistung

Falls Sie weitere Fragen haben freuen wir uns über eine E-Mail an die E-Mail Adresse: info@salcar.de. Wir antworten Ihnen innerhalb von 24 Stunden an Wochentagen oder 48 Stunden am Wochenende -:)

Alle Teile dieses Produkts, mit Ausnahme der Verschleißteile, haben eine 1-jährige Garantie. Schäden durch die folgenden Bedingungen sind nicht von der Garantie eingeschloßen:

1. Überladen des Trolleys
2. Von Menschen verursachte vorsätzliche Beschädigung
3. Schäden, die über die Garantiezeit hinausgehen

Salcar GmbH

Address: An der Hebemärchte 6, 04316 Leipzig, Germany

E-Mail: info@salcar.de

Tel: 0049(0)341 9276024

Web: www.salcarmall.com

世基株式会社 カスタマーサービスセンター

〒700-0973 岡山県岡山市北区下中野722-112-101

TEL:086-206-6136

受付時間:月~金 9:30~15:00 (土・日・祝祭日、年末年始を除く)

E-mail: amazonjp@sekeyec.com

Sekey Group Corporation

Address: 2 E VALLEY BLVD APT 280, ALHAMBRA, CA 91801

Email: info@sekeygroup.com

Web: www.sekeygroup.com